Application & Guidance Notes

Safety Limit Switches



Safety Circuits

When installing a safety switch, it is imperative that it is used in an approved circuit design. The essential requirements are:

1. The machine must stop when the guard is opened or the rope operated emergency stop is pulled.

- 2. The machine must not be able to be re-started with the guard open or before the rope switch is reset
- 3. The machine must not re-start automatically when the guard is closed or the rope switch is reset the 'start' or 'on' push-button should still need to be pressed.

Safety switch design principles

Positive Break

An important principle of a safety switch is positive break i.e. forced mechanical disconnection of the safety contacts in the event of contact weld. The system should not rely on spring pressure as this may not be sufficient to break the weld.

Security

When switches are used on machine guards, it is essential that the mechanism should not be defeated easily i.e. operators should not be able to override the switch either accidentally or intentionally. Switches that can be activated by the operator leaning on a plunger or inserting various objects (screwdrivers etc.) into the mechanism are not acceptable.

Fail-safe

In the event of component failure, the switch must fail with the safety contacts open

Reliability

It is very important that the mechanism should function reliably everytime it is used which means a high quality assembly with very little wear in use, giving a lifetime in excess of one million operations.

Strength

In an industrial environment, safety switches can receive severe impacts and


many other forms of physical abuse. It is essential that the switches can withstand this treatment without breaking.

Sealing

The working conditions can be extremely dirty with swarf and other foreign matter present. It is critical that the design should not allow any particles to enter the mechanism which could prevent it from operating.

Complete Electrical Separation of NO and NC Contacts

The British and European Standard BS EN 60947 shows three changeover contact configurations, two of which can be used in separate NO and NC circuits, but only one, the Zb arrangement, has completely electrically separate NO and NC contacts. The design of the Zb contact should be such that if one contact welds, the resultant imbalance of the mechanism, before the weld is forcibly broken, should not allow the NO and NC circuits to short-circuit:



The IMO Safety Limit Switches meet all these requirements:

Positive break of the safety contacts Tamper-proof Fail-safe Reliable Strong
Sealed against contamination
Electrically separate NO and NC contacts

The **European Machinery Directive**, which came into force on 1st January 1995, requires machinery manufacturers to ensure that their equipment conforms to all relevant safety standards. The use of **IMO Safety Limit Switches** will protect machinery and equipment to assist in meeting these standards

Specification

Rated thermal current Ith	10A
Rated working voltage	500VAC/600VDC
Initial contact resistance	<25 m0hms
Contact gap	>2.5mm (2 x 1.25mm conforming to VDE 0660 part 206)
Contact material	silver
Dielectric strength	2000VAC, 50/60Hz for 1 minute between open contacts 2000VAC, 50/60Hz for 1 minute between current-carrying parts and ground
Ambient operating temperature	-25 to +80 deg. C
Ambient humidity	95% r.h.
Maximum wire size	2 x 1.5mm² flexible, 2 x 2.5mm² solid
Conduit entry	PG13.5

Contact ratings

BS EN 60947-5-1 AC15 – Control of AC electromagnetic loads>72VA sealed – replaces AC11	230VAC 400VAC 500VAC	6A 4A 1A	DC13 – Control of DC electromagnetic loads where the time in ms taken to reach 95% of the rated current is equal to 6 times the power of the load (where P<50W)	24VDC 125VDC 250VDC	6A 1.1A 0.4A	
	SUUVAG	IA	- replaces DC11			


SafeLimSwitch/03/03 www.imopc.com


Application & Guidance Notes


Safety Limit Switches (continued)


If limit switches with positive break of the NC safety contacts are used in safety applications, it is essential that they are used in the positive mode, i.e. opening the guard should operate the switch, forcibly breaking the NC

When the door is opened, the switch must be pressed directly (fig 2) or by a cam (fig 3). Only in this way the positive opening of the NC contacts (11-12 and 21-22) is assured.









Any information or application examples including connections, illustrated in this document, must be intended as purely descriptive.






Figure 1 shows switches used in the negative mode, i.e. opening the guard

